

3-Fan Installation

Installation Guide

Required Hardware



3-Fan Tray (x1)
Mounting Brackets (x2)
M6 Screws (x4)



8mm Spanner

Door Installation

1. Install one (1) mounting bracket on the non-gland side of the fan tray using two (2) M6 screws.



bracket on fan without screws



bracket on fan with screws

3-Fan Installation

Installation Guide

2. Once the bracket is secured, position the bracket in line with the venting and slide through.



align the bracket with the venting



Push bracket through venting

3. Turn the fan so it sits against the venting and insert the second mounting bracket, securing with two (2) M6 screws.



3-Fan Installation

Installation Guide

4. Tighten the four (4) M6 screws using a 8mm spanner, once tightened installation is complete.



Installation Guide

1. Install one (1) mounting bracket on the either end of the fan tray using two (2) M6 screws.



pins lined with venting



3-Fan Installation

Installation Guide

4. Install one (1) mounting bracket on the opposite end end of the fan tray using two (2) M6 screws.



pins lined with venting and pushed through the venting



Screws loosely installed into bracket and fan tray



secure screws to complete fan tray installation

5. Once the screws have been tightened, the fan tray installation is complete.

